

MYSTIC MOTORIZED SCREEN

INSTRUCTIONS TO CUT DOWN A HOUSING

NOTE: AN EXISTING SCREEN PANEL WILL NOT WORK IF THE HOUSING IS CUT DOWN MORE THAN 3/8"

You will need the following:

1. Electric Drill with 5/32" Drill Bit.
2. 5/32" Rivets – 4 pieces
3. Rivet Gun with adapter to fasten 5/32" Rivet
4. Chop-saw with blade suitable for cutting non-ferrous metals (preferably a 14" chop-saw).
5. Speed Square
6. Pencil

(a) Remove the motorized screen and tube assembly from the housing.

(b) Remove one side cap from the back of the housing by drilling out the 4 rivets that secure the end cap to the back section of the housing.

(c) Using a speed square and pencil mark a line from the center of each of the existing 4 rivet holes so that you know where to drill the new rivet holes.

(d) Using the chop-saw cut the desired amount off the back section of the housing and equally off the front cover of the housing.

(e) Using the drill with the 5/32" drill bit, drill the 4 new rivet holes in the marked locations on the back section of the housing.

(f) Rivet the side cap back on to the back section of the housing using 5/32" rivets.

You may now proceed normally with the installation of the unit.

FOR ADDITIONAL ASSISTANCE CALL US AT 678-926-9700